

Bulk Micromachining: An Etch Process

Activity

Participant Guide

Introduction



Backside of Pressure Sensor before and After Anisotropic Etch

This activity is part of two SCME Learning Modules:

- Etch Overview for Microsystems
- MTTC Micro Pressure Sensor Process


Before completing this activity, you need to have completed the reading materials (PK) and other required activities in at least one of these learning modules.

This activity demonstrates the anisotropic etch process, which is considered a bulk micromachining process because it removes a select bulk of silicon wafer. It is the last step in a 10 step process* for making a micro pressure sensor. The micro pressure sensor design used in this process incorporates a Wheatstone bridge configuration on a silicon nitride membrane on the frontside of the chip. The backside of the chip is etched to remove a bulk of the silicon from beneath the membrane, forming a cavity. This cavity or chamber is used by the micro pressure sensor as the reference pressure chamber.

The micro pressure sensor process used at the Manufacturing Technology Training Center (MTTC) at the University of New Mexico uses KOH (potassium hydroxide) as the etchant. This activity uses a high concentration drain cleaner (sodium hydroxide), as a substitute for KOH. In this etch process wafers are submerged in a heated bath of a drain cleaner mixture. The drain cleaner is used because, like KOH, it produces an anisotropic etch with silicon by etching along the planes of the silicon.

Silicon nitride on the non-metal side (backside) of the chip acts as a hard mask on the chip. This mask leaves select areas of the silicon exposed to the drain cleaner. The exposed silicon is etched anisotropically by the drain cleaner. The etch continues until all of the exposed silicon is removed and the silicon nitride membrane on the front side of the chip is reached. KOH cannot etch silicon nitride; therefore, the etch stops when the silicon nitride layer is reached.

The image to the right shows a backside etch. The brown indicates the silicon nitride membrane on the frontside of the chip. As you can see the backside (or silicon) has been etched to create an opening or chamber beneath the membrane. The top of the wafer is the (100) plane while the etched sides of the chamber are formed by the (111) plane of the silicon.



Drain Cleaner Description and Parameters

In this activity a single die from a processed wafer is submerged in drain cleaner to anisotropically etch the exposed silicon. It is very important to purchase the right kind of drain cleaner. It is highly recommended that you use 100% Sodium Hydroxide (lye) crystal drain cleaner as the etchant. The drain cleaner will be diluted during the experiment with de-ionized (DI) or distilled water. Many drain cleaners have concentrations of sodium hydroxide that are less than 100% and they contain other additives. These drain cleaners should be avoided.

It is also very important to note that this etchant will be heated and will emit toxic fumes. It will also emit hydrogen gas.

Therefore, you **MUST** perform this experiment under a fume hood. There should be no exceptions.

Experiment Preparation: Approximately 30 minutes

Process Time: Approximately 2.5 to 3.5 hours

Chemicals Used: 100% Sodium Hydroxide (NaOH) in crystal form

*The 10 step process was developed jointly by the University of New Mexico (UNM) and Central New Mexico Community College (CNMCC)


Activity Objectives and Outcomes

Activity Objectives

- Describe the process of wet anisotropic etch of silicon.
- Identify the safety requirements when performing the wet anisotropic etch process.

Activity Outcomes

Upon examination, the exposed silicon is etched anisotropically leaving a thin silicon nitride membrane on the front side of the wafer. The images below are what you should see upon completion of the etch process.



*Frontside of an Individual Chip after Processing is Complete (far left)
Backside of an Individual Chip after Processing is Complete (right image)*

Safety

This activity uses sodium hydroxide drain cleaner. It is important to study the Material Safety Data Sheet (MSDS) prior to performing this activity and to follow safe chemical handling procedures when performing this activity. All participants should wear impervious protective clothing including shoes, gloves, and lab coat / apron. Safety goggles and/or a full face shield are required. This experiment should be performed in an area with an eye wash station and safety rinse area.

This experiment must be performed in a laboratory with a fume hood.

The following personal protective equipment (PPE) is required when performing this activity:

- Latex or nitrile gloves
- Safety goggles

Supplies/Equipment

This activity requires the SCME kit called **Bulk Micromachining: An Etch Process**. This kit can be ordered through the SCME website (<http://scme-nm.org>) while supply lasts and center is funded.

Supplies provided by instructor

- Crystal Drain Cleaner – 100% Sodium Hydroxide (NaOH) or lye (can be purchased from a home improvement center)
- DI (de-ionized) or Distilled water (a gallon of distilled water can be obtained from a grocery store)
- Paper cup
- Plastic spoon
- Plastic glass
- Hotplate with thermocouple control and ceramic top (if possible)*
- Microscope
- Latex or nitrile gloves
- Safety goggles

*Sodium hydroxide does react with certain metals.

Kit supplies

- 1 Liter beaker
- 6 Pre-processed etch chip
- 1 - 6 in Teflon tubing with additional chip
- 1 Weighing Scale (with 100g weight for calibrating)
- 1 Etch Overview for Microsystems Learning Module - Instructor Guide
- 1 Etch Overview for Microsystems Learning Module – Participant Guide

Preparation/setup

Before performing this activity, put on your latex or nitrile gloves and your safety goggles. Make sure you work under a fume hood and that the work surface is well protected in case of spills.

Facility

This activity MUST be performed under a working fume hood and in a facility with an eye wash station and rinse area (e.g., safety shower).

Activity: Anisotropic Etch of Silicon

Description: Perform a wet anisotropic etch of silicon using sodium hydroxide to create a cavity on the backside of a silicon chip.


Safety Data Sheet (SDS) (SDS used to be MSDS or Materials Safety Data Sheet)

1. From the Internet, download the SDS for sodium hydroxide. Study the SDS and answer the following questions.
2. Answer the following question before proceeding with this procedure.
 - a. Why is it important to wear goggles, gloves and protective clothing when working with sodium hydroxide?
 - b. Why is it important to perform this activity under a fume hood?
 - c. What measures should you take if sodium hydroxide comes in contact with your skin?

NOTE: Anytime you work with chemicals, it is your responsibility to know the chemical you are working with, know the necessary precautions, and follow ALL safety procedures (i.e., handling, personal protective clothing, first aid measures, disposal) when working with the chemical.

Anisotropic Etch Procedure


1. Set the hot plate to 105°C. It takes some time for the hotplate to reach this temperature.
2. While the hotplate is heating, place the pressure sensor die in the Teflon holder. Ensure that the die is placed with the corner in the holder and the backside facing out (*as shown below*).



Pressure Sensor Die in Teflon Tubing Holder

3. Measure 600 mL of DI or distilled water into the 1 Liter beaker.
4. Place the paper cup on the scale. The scale might need to be calibrated. If so, use the instructions included with the scale to calibrate the scale.
5. Scoop enough crystal drain cleaner (NaOH) into the paper cup to measure 100 g.
6. VERY slowly add the 100 g of NaOH to the water in the 1 Liter beaker.
 - Remember, **Always Add Acid (AAA)** to water, and never the reverse. NaOH is a very strong base, but it should be treated as an acid. When NaOH is mixed with water, the reaction is highly exothermic. A large amount of heat is released. If you add water to NaOH, you initially form an extremely concentrated solution. Before you can completely add all of the water, the released heat from the NaOH and H₂O causes the solution to boil very violently, splashing concentrated NaOH out of the container! If you add the NaOH to water, the initial solution is very dilute and the small amount of heat released is not enough to vaporize and spatter it. AAA allows the heat to be released and to dissipate, preventing a violent reaction. This is the same reaction that can occur for acids and water; therefore, treat NaOH as an acid. Remember – it's also highly corrosive.


7. Once all of the NaOH has been added to the water, place the Teflon tube with die side down into the NaOH solution.
8. Swirl the Teflon tube in the solution to further dissolve the NaOH crystals.
9. Place the beaker with the solution and the Teflon tube with the die on the hotplate.
10. Insert the hotplate's thermocouple into the flask.
11. Monitor the temperature and allow the solution to come to 105°C.
 - Even though the solution should already be hot due to the exothermic reaction between the NaOH crystals and the water, it may take some time for the solution to reach 105°C.
12. The temperature should be monitored and should maintained at 105°C.
13. Notice the bubbles forming as the silicon is being etched. (See image below). This is the NaOH etching the silicon.



Pressure Sensor Die in KOH Solution

14. It should take between 2.5 to 3.5 hours for the bulk of the silicon on the back side of the die to be removed or etched away. You can tell the process is complete if you can see light through the holes in the die.
15. Once you can see light through the devices, carefully remove the die from the solution.
16. Pour DI or distilled water into the plastic glass. Gently rinse the die in the DI or distilled water.

17. Through a microscope, view the etch on the backside of the die.



*Backside of Pressure Sensor Illustrating the Bulk Etch of the Silicon
Courtesy of Keyence*

Post Activity Questions

1. What is meant by "anisotropic etch"?
2. What characteristic of silicon allows for its anisotropic etch with KOH (or NaOH)?
3. What type of micromachining process does this activity simulate (surface, bulk, or LIGA)?
4. What are the important safety procedures that must be followed when performing this experiment?
5. This process is just one type of anisotropic etching. Some anisotropic etching occurs within a plasma etcher and affects a thin film on the surface of a wafer, thus being a “surface” micromachining process. However, the process you just performed is considered a “bulk” micromachining process. Explain why.

Disclaimer

The information contained herein is considered to be true and accurate; however the Southwest Center for Microsystems Education (SCME) makes no guarantees concerning the authenticity of any statement. SCME accepts no liability for the content of this unit, or for the consequences of any actions taken on the basis of the information provided.

Support for this work was provided by the National Science Foundation's Advanced Technological Education (ATE) Program through Grants. For more learning modules related to microtechnology, visit the SCME website (<http://scme-nm.org>).